

Labels




Fig. 1-1 Location of the serial number on the underside of the detector head




Fig. 1-2 Location of the serial number in the module cavity